

Voltage code table

DRAS09 ... DRAS16 and DRASL09 ... DRASL16 enclosed DOL starters

Type

DR **AS16** - **26N**

AS
ASL

Contactor type
AC operated
DC operated

AS contactors
AC coil code
50 Hz 60 Hz

20	S	24 V	24 V
21	S	42 V	42 V
22	S	48 V	48 V

16	N	-	120 V
23	N	110 V	110 V
24	N	115 V	115 V
25	N	220 V	220 V
26	N	230 V	230 V
27	N	240 V	240 V

13	P	380 V	380 V
17	P	-	277 V
28	P	400 V	400 V
29	P	415 V	415 V

ASL contactors
DC coil code

81	S	24 V
83	S	48 V

Control supply wiring

S Separate supply

N Phase-to-neutral

P Phase-to-phase